











## INTRODUCTION

Ultra Max headphones are exactly what you need to stay on the go while also looking stylish. These fast charging headphones ensure that you are back to doing listening faster than ever so no more sitting around waiting for a charge. They have many different functionalities which comes in handy on the go. They are truly a fashion forward audiophile headset.

#### PACKAGE CONTENTS

1x UltraMax headphones 1x Charging Cable

### SPECIFICATIONS & FEATURES

- Comfortable fit
- Bluetooth v 5.0
- Noise Isolating
- Stylish Design • Up to 4 Hours of Continuous Play
  - TF Card / AUX / Type C



#### PRODUCT OVERVIEW



# **HOW TO USE**

# **Charging Headphones:**

- 1) Charge the headphones by plugging them in with given charger 2) Indicator light will blink blue when they need to be charged
- 3) Indicator light will be red while low power charging

# Pair Headphones:

- 1) Turn on headphones by holding power button
- 2) Headphones will say "ready to pair
- 3) Select "UltraMax" from your device's Bluetooth Interface

- Listen to Music: 1) Use your Phone's interface to select your music.
- 2) Use top button to go back or skip songs to play and pause buttor 4) Hold appropriate button to change the volume

## Listening to Radio:

- 1) Press power button
- 2) Use top button to scroll through stations
- 3) Press power button to switch back to bluetooth

# Using MicroSD (TF) Card Slot - Max Capacity is 16GB

- 1) Insert the Micro SD (TF) Card or USB Drive preloaded with songs.
- 2) Headphones will automatically start playing songs

3

# CARE AND SAFETY

- Do not use this unit for anything other than its intended use.
   Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
   Do not expose the device to extremely high or low temperatures, as it may damage the battery.
   Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- to yoursen and damage to the unit.

   Do not use the unit if it has been dropped or damaged in an
   Repairs to electrical equipment should only be performed
  may place the user at serious risk.
   Keep the unit out of reach of children.
   This unit is not a toy.
- ned by a qualified electrician. Improper repairs

BATTERY DISPOSAL-This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. Please refer to your local and state laws for battery disposal procedures.