


SLENDER

Bone Conduction



TWS44 User Manual

INTRODUCTION

Discover the future of audio with our innovative Bone Conduction Earbuds, designed for comfort, convenience, and clarity. Unlike traditional earbuds, these cutting-edge devices use bone conduction technology to transmit sound vibrations through the bones of the skull directly to the inner ear, bypassing the outer and middle ear. Perfect for active lifestyles, they offer a secure fit for running, cycling, or working out.

SPECS & FEATURES

- True Wireless Stereo
- Water Resistant
- 4 hours of playtime
- Pre-paired Technology
- Bluetooth range 35 Feet
- 1 hour quick charge

PRODUCT OVERVIEW



HOW TO USE

Charging Case:

Place the earbuds in the charging case. Connect the case to a power source using the included cable. A light indicator will show the charging status (check the manual for specific light indications).

Automatic Pairing

Place both headphones over your ears, with the transducers resting over your ears. On your device (smartphone, tablet, etc.), go to the Bluetooth settings, search for new devices, and select the headphone name (Bluestone Slender) from the list. Once connected, you'll hear a confirmation tone or see a steady light.

Using Controls

Use the touch-sensitive areas to play, pause and stop music. Answer or end calls with the multifunction button. Double tap right touch sensitive areas for volume up. Double tap left touch sensitive area for volume down.

Making and Receiving Calls

Tap the touch sensitive area once to answer or end a call. Tap and hold the touch sensitive area to reject an incoming call.

Power Off and Storage

Tap and hold the power button to turn off the earbuds, or place them back in the charging case.

CARE AND SAFETY

Keep the earbuds in the charging case when not in use to protect and charge them.

PACKAGE INCLUDES

- Earbuds x 2
- Charging Case
- Type-C Charging Cable